



# Cloud VTX-WM1 - Screen Shots 3

Setting up load testing for each amplifier channel in the VTX-WM1

Shopping Centre  
Product Monitor and Control

[Home](#) [CloudNET](#) [Config](#) [Contact Us](#)

/Config

Log out

Site

Lower Floor

L1 - Supermarket

**L32 - Clothes Shop**

Tests

Event Log

Food Court

Adjust the settings then click Apply.  
Click reset then apply to return to factory defaults.  
Scroll down the pane to reach further settings.

## L32 - Clothes Shop: VTX4400

### Test List

Load Configuration				
Channel	Frequency	Tolerance	Expected	
Ch 1	60Hz	10%	Unknown	<input type="button" value="Config"/> <input type="button" value="Test"/>

---

Scheduled Tests					
Ch 2	16000Hz	30%	2011-02-24 04:10:00	5.63	<input type="button" value="x"/>
Ch 3	16000Hz	30%	2011-02-24 04:15:00	4.93	<input type="button" value="x"/>
Ch 1	60Hz	10%	2011-01-10 09:28	<input type="button" value="grid"/>	Unknown <input type="button" value="+"/> <input type="button" value="x"/>

© 2010 Cloud Electronics  
Version 5.3 AJAX

